


# CLIN6 Assembled



## Item list:

Panel 1, 28" wide

Panel 2, 28" wide

Panel 3, 28" wide

Two flat aluminum connector plates

Two flat steel connector plates

LC Pedestal sets (2 pieces per set):

2 sets at 25.125" wide

1 set at 24" wide

21 (2.5"x .375") bolts, 21 nuts, 42 washers

42 decorative bolt head covers

## Torque settings:

Torque all securing bolts to approximately 40 ft/lbs. to insure integrity of the system.

## Time allowance:

2 installers, 25 minutes

## Installation notes:

All fiberglass panels are 47" tall. Only the width varies.

1) The return and end panels are framed on 3 sides. Inside panels are framed on two sides.

2) Fiberglass can irritate the skin. Always wear gloves before handling fiberglass.

3) Try to avoid putting pressure on the tackable fabric surfaces to avoid "dents".


Avoid point pressures from hands or knees.

4) Insure that each panel is tight against the adjacent panels to insure "gap free" connections. This will maximize ballistic protection.

5) Be sure that the panels are perfectly vertical before tightening the pedestal bolts. Adjust the position of the pedestals as needed to get the panels vertical.

# CLIN6 Exploded view

Figure 1



1. Working with one panel at a time, stand each panel upright and perfectly vertical. Attach LC Pedestal sets to each panel using the 3/8" bolts, washers and nuts.
2. Once all three panels are standing on their own, position the panels together as shown above in figure 1. Be sure to insert the alignment tabs into the upper frame rails on each panel. This allows for perfect alignment from one upper frame rail to the next.
3. Place the metal connector plates on the safe side, and the aluminum connector plates on the attack side. Use the 3/8 bolts, nuts and washers to secure the system together.
4. Once the system is secure, push the decorative trim caps onto each bolt head and nut to finish the installation.